


INTANK FUEL FILTERS

JI2500(ZL05-20-490A)



JI2501(GY01-13-ZE0)



JI3300(16400-4M405)



JI3301(16400-2Y505)




JI3302(16400-2Y921)



JI4100(92193770)




JI6300(23300-21010)



JI6301(23300-23030/40)



JI6302(23300-28030/40)



JI6303(23300-21030)




JI6304(23300-74330)




JI6305(77024-33060)




JI6306A(77024-12050)



JI6500(MR526974)














JI6501(MR431453)




JI6502(MR552781)



INTANK FUEL FILTERS

JI6503(MR450543) 	JI6504(MR431096) 	JI6505(MR450542) 	JI6506(MR906933) 
JI6507(MR514676) 	JI7300(16010-SDC-E01) 	JI7301(16010-S84-A01) 	JI7302(16010-S3N-000) 
JI7303(16010-S5A-932) 	JI7304A(16010-SAA-000) 	JI7305A(17048-SEW-T00) 	JI9300(31911-2D000) 
JI9301(31911-2E000) 	JI9302(31112-1C000) 	JI9303(31112-17000) 	JI9304(31112-26000) 

INTANK FUEL FILTERS

JI9305(31911-09000) 	JI9306(31911-09100) 	JI9307(31112-1G000) 	JI9500(OK52Y-20-490) 
JI9501(31911-3E200) 	JI9502(31911-38204) 		